

WINTERIZING YOUR RV

FIRST THINGS FIRST

- Decide if you will be taking your RV to a maintenance shop or winterizing it yourself

DOING IT YOURSELF?

- Prepare the interior and exterior:
 - Empty and clean the entire RV out
 - Check the inside and outside for cracks that need to be re-sealed
 - Clean/wash the outside
 - Take action to eliminate any existing odor
- Consult your owner's manual for winterizing instructions, valve locations, or if you are confused

DRAIN AND ANTIFREEZE

- Drain the entire plumbing system and fill it with antifreeze
- Fill the radiator and windshield washer with a solution containing antifreeze

ENGINES, TIRES, AND BATTERIES

- Fill the tank, get a stabilizer, run the engine, etc.
- Check the tire pressure and inflate to the recommended pressure, protect them using leveling jacks/outside jacks/by rotating them a few times during the winter, for extra precaution put something between the tires and the ground
- Fully charge, remove, and safely store the batteries OR plan to leave the batteries in and fire up your RV once a month and plugging it in to shore power for 8 hours

STORAGE

- Store your RV somewhere dry, covered, and on solid ground and if you can, check on your RV a few times during the off-season

INSURANCE

- Talk to your agent
- Take an inventory and check your policy for programs, discounts, limits, and exclusions

Does your family need help preparing for a move?

Call today for free insurance advice.

855-244-7671

